




1. Go to www.pct-ag.com, then click on AgCloud login



2. Enter your Username and Password



4. Click on Gateway, then Install Gateway



5. Then follow the installation instructions from Page 8 in the attached Gateway User Manual

